

## T92 overhaul of the shafts

When the T92 system does not lock anymore on the main shafts, an overhaul is needed.

Polish the shafts with Scotch Brite.

Pull it around the shaft while you move slowly from one end to the other side of the shaft.



It is even better to put the shafts in a lath and polish it there.

All new shafts are treated in this way.

Kind regards

Fred